



WWW.METRICFATS.COM

M109-R Rear Blinker Installation

- 1-Remove seat and body panel**
- 2-Remove 4, 10mm bolts that hold the stock plastic turn signal in place**
- 3-Cut off the turn signal / plate holder, flush. A utility knife works well.**
- 4-Reinstall newly trimmed piece with the 10mm bolts and place the back body panel on.**
- 5-Take the RAW Turn Signal bracket, place under back body panel and line up with edge of fender. The ends of the RAW bracket should touch or be close to the seat supports. Mark the 3 small bracket holes.**
- 6-Take the body panel back off and drill the marked holes with a 3/16" drill bit.**
- 7-Install the RAW signal bracket**
- 8-Run the new wires along the stock harness holder. Cut off the connectors from your old signal wires and connect to new signal wires.**
- 9-Reinstall the back body panels and adjust RAW signal as desired. Test blinkers.**
- 10-Reinstall your seat and ride safe.**

If you have any questions, please do not hesitate to call our tech. support line during normal business hours, Eastern Standard Time. 203-425-3214. Or email Info@Metricfats.com