




RUN/TURN/BRAKE Wiring.

ALWAYS DISCONNECT BATTERY FROM BIKE BEFORE PERFORMING ANY ELECTRICAL WORK.

Modern electronics are sensitive to current spikes and are therefore not covered under warrantee.

- 1) Wire to LED signal as shown in upper part of picture
- 2) Left and right Legs shown in Lower part of picture attach to corresponding (Left, Right) signals. Red to positive – Black to negative.
- 3) Center wires-Red is Brake, Yellow / orange is running. Attach to corresponding circuit from bike.



Please do not hesitate to call with any questions.

203-425-3214

info@rawdesigncycles.com